

DAN JUDY AUTOMOTIVE, INC.
1560 COMMERCIAL ST NE
SALEM, OR 97303
503-362-5830

Maintenance: Normal Service 30000 MI or 48000 KM

Inspect

Brake Hose/Line.....

Cooling System.....

Check the coolant level, hoses, and clamps.

Exhaust System.....

Fluid – A/T.....

Fluid – M/T.....

Suspension.....

Inspect the front suspension components.

Replace

(E) Air Filter Element.....

Engine Oil.....

Oil Filter, Engine.....

(E) Spark Plug.....

Rotate

Tires.....

-
- (S) = Service Warranty Requirement
 - (E) = Emission Warranty Requirement
 - (B) = Both Service and Emission Warranty Requirement

**DAN JUDY AUTOMOTIVE, INC.
1560 COMMERCIAL ST NE
SALEM, OR 97303
503-362-5830**

**Maintenance: Service Intervals
Routine Service Defined**

Vehicles that do not operate under the severe conditions that are listed below use the Routine Service Schedule.

- Day or night temperatures are below 0°C (32°F).
- Stop and go driving.
- Extensive engine idling.
- Driving in dusty conditions.
- Short trips of less than 16 km (10 miles).
- More than 50% of your driving is at sustained high speeds during hot weather, above 32°C (90°F).
- Drag Race Operation.
- Heavy Loading.
- Taxi, police, or delivery service (commercial service).
- Off-road or desert operation.
- If equipped for operating with E-85 (ethanol) fuel.

At Each Stop For Fuel

- Check the engine oil level about 5 minutes after a fully warmed engine is shut off. Checking the oil level while the vehicle is on level ground will improve the accuracy of the oil level reading. Add oil only when the level is at or below the ADD or MIN mark.
- Check the windshield washer solvent and add if required.

Once A Month

- Check tire pressure and look for unusual wear or damage.
- Inspect the battery and clean and tighten the terminals as required.
- Check the fluid levels of coolant reservoir, brake master cylinder, and transmission and add as needed. Check all lights and all other electrical items for correct operation.

At Each Oil Change

- Change the engine oil filter.
- Inspect the exhaust system.
- Inspect the brake hoses.
- Inspect the CV joints (if equipped) and front suspension components. Check the automatic transmission fluid level.
- Check the manual transmission fluid level.
- Check the coolant level, hoses, and clamps.

DAN JUDY AUTOMOTIVE, INC.
1560 COMMERCIAL ST NE
SALEM, OR 97303
503-362-5830

Maintenance: Service Intervals
Maintenance Schedules Defined

There are two maintenance schedules that show the required service for your vehicle.

First is Severe Service. It is for vehicles that are operated under the conditions that are listed below.

- Day or night temperatures are below 0°C (32°F).
- Stop and go driving.
- Extensive engine idling.
- Driving in dusty conditions.
- Short trips of less than 16 km (10 miles).
- More than 50% of your driving is at sustained high speeds during hot weather, above 32°C (90°F).
- Drag Race Operation.
- Heavy Loading.
- Taxi, police, or delivery service (commercial service).
- Off-road or desert operation.
- If equipped for operating with E-85 (ethanol) fuel.

Note: Most vehicles are operated under the conditions listed for Severe Service Schedule.

Second is Routine Service. It is for vehicles that are not operated under any of the conditions listed under Severe Service Schedule.

Use the schedule that best describes your driving conditions. Where time and mileage are listed, follow the interval that occurs first.

CAUTION: Failure to perform the required maintenance items may result in damage to the vehicle.

**DAN JUDY AUTOMOTIVE, INC.
1560 COMMERCIAL ST NE
SALEM, OR 97303
503-362-5830**

Maintenance: Service Intervals

Maintenance Schedule Definitions

MAINTENANCE SCHEDULE DEFINITIONS

Maintenance schedules are provided in two different formats:

1. Schedules that use a specific mileage interval for service and a specific type of driving to determine when service is required.
2. Schedules that use a maintenance indicator to determine when a specific service will be required.

VEHICLES WITH MILEAGE INTERVALS

ROUTINE SERVICE

This article lists maintenance items that do not follow any specific mileage interval pattern, such as "Monthly", "As required" or "Periodically".

NORMAL SERVICE

This schedule lists maintenance recommended at specific mileage intervals for vehicles used for general transportation.

SEVERE SERVICE

This schedule lists maintenance recommended at specific mileage intervals for vehicles used under extreme conditions.

VEHICLES WITH MAINTENANCE INDICATOR

Follow the manufactures instructions for the services required. Use the Normal or Severe procedure when provided, and perform any additional service when required.